

## Windows Laptops/Netbook related

### Lenovo laptop one key rest to factory default

Just press the "NOVO button", the upside down U. No need to press the power button.

<https://support.lenovo.com/ca/en/solutions/ht503785>

Unique solution ID: #1009

Author: n/a

Last update: 2017-08-16 23:06