

## Windows Laptops/Netbook related

### Brand Windows laptops' USB Flash Drive Boot Reference List URL

<https://craftedflash.com/info/how-boot-computer-from-usb-flash-drive>

Samsung notebook boot select key: F10

Unique solution ID: #1010

Author: n/a

Last update: 2017-08-16 23:06