Windows Laptops/Netbook related

Laptop cannot power on by pressing the power button. Unit can charge (Charging LED is on when plug-in AC adapter)

Check the power buttion board and related cable.

Unique solution ID: #1015

Author: n/a

Last update: 2017-10-27 22:24