

Windows Laptops/Netbook related

**Laptop cannot power on by pressing the power button.
Unit can charge (Charging LED is on when plug-in AC adapter)**

Check the power button board and related cable.

Unique solution ID: #1015

Author: n/a

Last update: 2017-10-27 22:24