

Windows Laptops/Netbook related

Asus notebook network RJ-45 jack cover removal.

Slide down and push out the RJ-45 jack cover.

Unique solution ID: #1018

Author: n/a

Last update: 2017-11-06 23:46