

## Windows Laptops/Netbook related

### Unknown USB Device (Device Descriptor Request Failed) - Webcam not working

Reason: Some time it was loss connection.

Solution: Open Webcam cover (screen plastic cover), push the webcam cable in.

Unique solution ID: #1019

Author: n/a

Last update: 2017-11-07 00:05