

Windows Laptops/Netbook related

Laptop cannot boot.

Scenario 1: Charging LED is not on

Scenario 2: Charging LED is on, but can not power on by pressing power button.

Unique solution ID: #1021

Author: n/a

Last update: 2017-11-07 01:20