

Windows Laptops/Netbook related

HP laptop only charge for few seconds then disconnect the charger.

Use right watts charger for the unit. Check unit's back cover for spect. 45W vs 65W or 120W

Unique solution ID: #1031

Author: n/a

Last update: 2018-05-11 17:16