

Windows Laptops/Netbook related

ALT+F10 = Acer Windows 10 reset to factory image key

Power on the unit, then press "ALT+F10" to bring the reset menu.

Unique solution ID: #1033

Author: n/a

Last update: 2018-03-29 18:01