

## Windows Laptops/Netbook related

### Samsung recovery key , rest to factory default

During the boot up, press "F4" key to enter the recovery.

F2: enter bios

F10: boot select.

If you need to boot to "DOS" using a USB device, enter the BIOS Setup, select the "Advanced" menu and set the "Fast BIOS Mode" item to "Disabled".

Unique solution ID: #1005

Author: n/a

Last update: 2017-08-24 16:59